

# Adhering and Sealing Exposed Stone and Bricks

## Priming

### Packaging

### Mixing



### Application



## Adhering Brick Tiles

### Packaging

### Mixing



### Application



## Grouting

### Packaging

### Mixing



### Application



## Sealing

### Packaging

### Mixing



### Application



## Substrates

Concrete  
Cement render  
Brick, Block  
Cement sheet

## Materials

**Primax** (two-pack primer), **Kemgrip Floor & Wall** mixed with **Elastacrete**, **Kemgrout Sanded** mixed with **Primebond**, **Natural Sealer**.

## Surface Preparation

All surfaces must be clean and sound and free of grease, dust, coatings and other contaminants. New concrete must have cured for 28 days or more.

## Workmanship

Apply products in accordance with the manufacturer's written instructions and good trade practice.

## Application

### Priming

Apply the mixed **Primax** only with a hard brush or broom, making sure to push the mixture firmly into the substrate.

### Tile Fixing

Fix the tiles with **Kemgrip Floor & Wall** mixed with **Elastacrete**.

### Grouting

Grout after adhesive has initially set, approximately 8-12 hours. Use **Kemgrout Sanded** mixed with **Primebond**.

### Sealing the Surface

Apply the **Natural Sealer** in two coats ensuring that the total surface is covered.

