

Tiling Floors Subject to High Point Loadings

Priming

Packaging Mixing







Tiling

Packaging Mixing



Application



Grouting

Packaging



Mixing

Application







Substrates

Concrete floors

i.e. car showrooms, garages, shopping malls and driveways

Materials

Primax (two-pack primer), Kemgrip Floor & Wall (cement-based, ceramic tile adhesive), Elastacrete (water-based, flexible, acrylic additive), Monoflex (polymer-modified, cement adhesive), Kemgrout (ceramic tile grout), Primebond (additive to Kemgrout).

Workmanship

Apply products in accordance with the manufacturer's written instruction, good trade practice and the Standard.

Surface Preparation

Existing Concrete

The surface must be clean and structurally sound and be free of dust, oil, grease, wax, paint and other contaminants. Remove oil, grease etc., with an industrial detergent e.g., Tri Sodium Phosphate or caustic soda solution. Wire brush or abrade to remove previous coating. Smooth concrete must be roughened mechanically and washed thoroughly and allowed to dry. Contaminated surfaces must be mechanically abraded.

New Concrete

Must be finished with a wood float and be allowed to cure for a minimum of 28 days before tiling. The surface must be free of dirt, dust, grease and release agents prior to tiling.

Priming

Prime all surfaces. Apply **Primax** to the substrate with a hard bristled broom.

Application

Adhere the tiles with **Kemgrip Floor & Wall** mixed with **Elastacrete** at a rate of 5-6 litres of liquid to


20kg Kemgrip Floor & Wall or use Monoflex (areas subject to heavy vehicle traffic must use Kemgrip Floor & Wall mixed with Elastacrete). The adhesive will flex, accommodating possible movement difference between the tile and the concrete whilst being sufficiently rigid to accommodate the stress and point loading of the weight of vehicles or pallet trucks. The adhesive will accommodate pedestrian traffic 24 hours after application. Driveways and car showrooms must set for 14 days at 23°C and 50% relative humidity before use, longer in cold conditions. Tiles must be a heavy duty, commercial grade (Rating 5) and be approved by the tile manufacturer for vehicle traffic.

Apply with a notched trowel. For tiles 400mm x 400mm or greater use a 12mm notch and butter tile back (as per the Australian Standard AS3958.1). The final bed thickness must not be less than 2mm for walls and 3mm for floors, to accommodate movement. Spread about 1 metre at a time. Tiles must be set in place while the adhesive is still wet on the surface. Press tiles firmly into the adhesive using a slight sliding motion. Tiles must be firmly bedded into the adhesive so no voids occur (100% adhesive coverage) beneath the tiles. **Do not** spot fix. Movement joints (5mm) to be at 5 metre grids, corners and room perimeters are filled with a silicone sealant.

Do not tile over movement joints in the floor.

A guide to tile joint sizes

Internal minimum 2mm, external minimum 4mm or as specified by the tile manufacturer and AS3958.1. **Do not** fix tiles with tight joints. When grouting joints of less than 3mm we recommend mixing the grout with **Primebond**. Greater care is needed to place the grout deep into joints before pointing the joints to compact the grout surface.



Dribond CONSTRUCTION CHEMICALS

Adelaide (08) 8243 7888 **Brisbane** (07) 3271 2944 **Melbourne** (03) 9761 4711

Perth (08) 9356 9999

Sydney (02) 9756 3533 **Auckland** (09) 273 5444 **Kuala Lumpur** (603) 5122 2522

www.constructionchemicals.com.au